



## Quick Start Guide



CM-7400

#### COPYRIGHT

©2011 Channel Master. All rights reserved. This document contains proprietary information protected by copyright. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Channel Master, 2260 W. Broadway Rd, Mesa, AZ 85202, U.S.A.

#### DISCLAIMER

IF THIS PRODUCT DIRECTS YOU TO COPY MATERIALS, YOU MUST HAVE PERMISSION FROM THE COPYRIGHT OWNER OF THE MATERIALS TO AVOID VIOLATING THE LAW WHICH COULD RESULT IN DAMAGES OR OTHER REMEDIES.

#### TRADEMARKS

Channel Master, Channel Master TV and “The Most Advanced Subscription Free HDTV Solution” are trademarks of Channel Master. All other trademarks are the property of their respective owners.

#### CHANGES

The material in this document is for information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, Channel Master assumes no liability resulting from the use of the information contained herein. Channel Master reserves the right to make changes in the product design without reservation and without notification to its users.

# Table of Contents

## Overview

- 2 Safety Instructions
- 4 Contents
- 6 Front Panel
- 7 Back Panel
- 8 Remote Control

## Step 1 - Connecting Video

- 14 High-Definition TVs
- 16 Standard Definition TVs

## Step 2 - Connecting TV Source

- 18 ATSC Antenna or Cable

## Step 3 - Connecting Audio

- 20 TV (Stereo)
- 21 A/V Receiver (Surround Sound)

## Step 4 - Connecting Network

- 22 Wired
- 23 Wireless

## Step 5 - Powering Up

- 24 Setting up Remote Control
- 25 Connecting to Power Source

## Appendix

- 26 Device Codes
- 35 Declaration of Conformity
- 36 Product Return Policy and Warranty



# Important Safety Instructions

**WARNING:** To prevent fire or shock hazard, do not expose this product to rain or moisture.

- Read these instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prongs are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- To reduce the risk of electric shock, DO NOT remove cover or back panel. No user serviceable parts inside. Refer servicing to qualified personnel.

- To help prevent electric shock, plug the power cable into properly grounded sources. Use only properly grounded extension cords and adapters, if they are needed.
- The AC main plug is used as the disconnect device, the disconnect device shall remain readily operable.
- Make sure nothing is lying on any of the cables.
- Be sure the cables are located where they will not be stepped on or tripped over.
- Do not spill food or liquids onto the unit.
- Do not push any objects into the free slots. Doing so will damage the unit, can cause fire or electrical shock, and can short out interior components.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not block cooling vents.
- Do not place the equipment in a closed-in wall unit.
- When you disconnect a cable, pull on its connector or on its strain relief loop, not on the cable itself. Some cables have a connector with locking tabs; if you are disconnecting this type of cable, press in on the locking tabs before disconnecting the cables.
- When you connect a cable, make sure both connectors are correctly oriented and aligned before connecting to avoid bending connector pins.
- For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.

# Contents



CM-7400 Unit



IR Universal Remote Control



(2) AA Batteries




AC Power Adapter



**RF Coaxial Cable**  
(For TV Sources)



**HDMI Cable**  
(For HD Video)



**Composite Audio/Video Cable**  
(For SD Video and Stereo Audio)




**Quick Start Guide**



**User Guide**


# Front Panel



Name	Function	Description
<b>1</b> POWER	Button	Solid Green indicates the unit is on. Solid Red indicates the unit is in standby mode. Flashing Green light indicates the unit is starting up. Press button once to put unit in standby mode, press again to resume. To restart the device, press and hold for at least 5 seconds or longer.
<b>2</b> LINK	Status LED	Green dot indicates that Ethernet or Wi-Fi network connection is active.
<b>3</b> CLOCK	4-Digit Clock	Clock displays current time, may not display time during restart process.
<b>4</b> RECORD	Status LED	Green dot indicates a TV program is currently recording.
<b>5</b> HD	Status LED	Green dot indicates current program is playing in HD (720p or higher) resolution.
<b>6</b> 7-WAY NAVIGATION MENU	Capacitive Touch Panel	Use <b>Back</b> , <b>Menu</b> , <b>OK</b> and <b>Directional</b> buttons to help with navigating the user interface without a remote control.
<b>7</b> USB 2.0	USB 2.0 Connector	To connect USB devices such as USB Flash Drive, External USB Hard Drive.



# Back Panel



Back Panel


Name	Description
1 eSATA	External Serial ATA Connector (May support future upgrades).
2 CABLE/ANT IN	For Clear QAM Cable TV Source and ATSC Antenna.
3 TV OUT	Connection to RF TV Output.
4 WI-FI	Wi-Fi antennas for extended range and coverage.
5 VIDEO	Composite Video (Supports SD Video).
6 COMPONENT VIDEO	Component Video Output (Y, Pb, Pr) (Supports HD Video).
7 AUDIO	Stereo Audio Output (Left / Right).
8 DIGITAL AUDIO	Digital Audio Output - Optical Connection (Supports 5.1 Surround Sound).
9 HDMI	HDMI Output (Supports HD Video and Multi-Channel Audio).
10 10/100 ETHERNET	Ethernet Port.
11 USB 2.0	USB Connector.
12 POWER IN	Power connection to AC adapter.



QSG

7

# Remote Control



Button(s)	Description
<b>1</b> POWER	Switches the power on / off for the currently selected device Switches STB to power on / standby mode.
<b>2</b> DEVICE CONTROL	<b>TV:</b> Select to control TV (if programmed). <b>STB:</b> This button is pre-programmed to control your Channel Master TV. <b>AUX:</b> Select to control another device (if programmed).
<b>3</b> ACTIONS	Controls video program for LIVE TV / DVR / VOD <b>REPLAY:</b> Go back a few seconds. <b>REW:</b> Rewinds video quickly. <b>FF:</b> Fast forwards video quickly. <b>SKIP:</b> Skips ahead in 30 second increments. <b>REC:</b> Starts recording program. <b>PAUSE:</b> Pauses video. <b>PLAY:</b> Plays video or resumes a paused program. <b>STOP:</b> Stops playback of video.
<b>4</b> SHORTCUT	Color-code buttons correspond to features that are enabled for quick access.
<b>5</b> MENU	Shows on-screen menu or home screen.
<b>6</b> INFO	Shows on-screen information about the current TV / VOD / DVR program.
<b>7</b> NAVIGATION	<b>ARROW KEYS:</b> Navigates up, down, left and right within the on-screen guide or menus. <b>OK:</b> Executes the currently selected menu option.
<b>8</b> EXIT	Exits the current menu item or out to LIVE TV.
<b>9</b> GUIDE	Shows the on-screen program guide.
<b>10</b> CH/PG	Changes channel up or down or pages up or down within on-screen program guide.
<b>11</b> LAST	Changes channel to the most recently viewed channel.
<b>12</b> NUMBERS	Allows direct access to specific channels and menu items.
<b>13</b> CC	Toggles closed captioning on or off.
<b>14</b> INPUT	Changes the current A/V input of the selected device programmed (i.e. TV or AUX). May be used when entering a period in certain channels.
<b>15</b> MUTE	Turns the volume of the currently selected device off and on.
<b>16</b> VOL + / -	Increases or decreases volume of the currently selected device.
<b>17</b> BACK	Goes back one level within menus.
<b>18</b> OPTIONS	Provides additional options for given on-screen menu or highlighted item.



# Remote Control

## Controlling Your TV and other A/V Devices

The Universal Remote Control (URC) can be used to control TVs and other A/V devices such as DVD players and recorders. The URC uses InfraRed (IR) light signals to control other devices that the remote is programmed to control. IR signals travel only short distances (40 feet or less), and cannot go through walls or other solid objects. You must point the remote control directly at these devices, with no objects blocking the line of sight.

You can program the URC to control one TV and one AUX device. Use the remote control's mode keys (i.e., "**TV**", "**STB**", or "**AUX**") to control a specific



device. When pressed, the selected mode key will light up confirming your choice. Then you can use the URC to control your Channel Master TV, TV or AUX device. You have to program the remote control to know what TV and AUX devices you are using by either:

1. Entering the 4-digit device code (see page 26).
2. Doing an auto search.

### NOTE:

- The "**POWER**" key can be configured to control both your Channel Master TV and TV while the remote control is in STB mode, please refer to the section "**Toggle Power Key Punch-through Functionality**" on page 11 for details.



- The “**Vol +/-**” and “**MUTE**” keys can be configured to control both your Channel Master TV and TV while the remote control is in STB mode, please refer to the section “**Toggle Power Key Punch-through Functionality**” on page 11 for details.



## To Program a TV or AUX device

1. Locate the device code for your desired device in the device code table provided in the Appendix on page 26. If you cannot find the device code for your device or it does not work after trying the listed device codes for your device brand, then you can try the auto search procedures on page 12.
2. Turn on your device and with media inserted (if applicable).
3. On the remote control, press a device mode key for 5 seconds (i.e., “**TV**” or “**AUX**”). The device mode key will light up.

**NOTE:** Use the “**AUX**” mode key to program control of VCR, DVD player, cable box, satellite set-top box and audio device.



4. Enter the four-digit device code for your device. If you perform this procedure correctly, the selected device mode key backlight will blink twice.

**NOTE:** If you enter an invalid device code, the selected device mode key will blink rapidly 7 times. Device program mode will be terminated.

5. Aim the remote control at your device and press the “**POWER**” key once. The device should be turned off. If it does not respond, repeat the above steps.



**NOTE:** In the programming mode, if no key is received within 30 seconds, the device mode key backlight will blink rapidly 7 times to indicate an error and then extinguish, and the programming mode will end.

## Toggle Power Key Punch-through Functionality

By default, if the remote control is in STB mode, the remote control “**POWER**” button switches your Channel Master TV off ONLY. To control the remote control “**POWER**” button functionality to switch off the TV and/or Channel Master TV, please do the following:

1. Press and hold the “**STB**” mode key for 5 seconds.



The “**STB**” device mode key backlight will light up.

2. Press “**POWER**” key once.
3. Do either of the following:
  - a. Press “**1**” to control both your Channel Master TV and TV, or
  - b. Press “**0**” to control your Channel Master TV ONLY

**NOTE:** In the programming mode if no key is received within 30 seconds, the device mode key backlight will blink rapidly 7 times to indicate an error and then extinguish, and the programming mode will end.

## Toggle Volume Key Punch-through Functionality

By default, “**Vol +/-**” and “**MUTE**” keys are sent to your Channel Master TV only when the remote control is in STB mode. Punch-through function for those keys is enabled at the same time when programming the device code is for TV or AUX. That is:

1. If the user program device code for a TV device, then the punch through function will be configured for TV at the **same time**.
2. If user program device code is for an AUX device, the punch through function will be configured for AUX at the **same time**.

To disable the Punch-through function for those keys, do the following:

1. Press and hold “**STB**” for 5 seconds, then the STB LED backlight will switch on.
2. Press “**STB**” key once again, then both STB and AUX LED backlights will switch on.
3. Press “**0**”.

## Auto Search Procedures

If your device does not respond to the remote control after trying all devices codes listed for you brand, or if your brand is not listed, try searching for your device code as follows:

1. Turn on your TV or your A/V device.
2. On the remote control, press a device mode key (i.e., “**TV**” or “**AUX**”) and hold for 5 seconds. The device mode key will light up.



**NOTE:** Use the “**AUX**” mode key to program control of VCR, DVD player, cable box, satellite set-top box, and audio device.



3. Press the “**POWER**” key once.
4. Aim the remote control at the device. Press either the “**CH UP**” key or “**CH DOWN**” key to do device auto-scan:



- a. Press the “**CH UP**” key to start searching upward at approximately 5 second intervals for each device code. The TV/AUX mode key will be on and blink every 5 seconds while in the device scan mode.

**NOTE:** In this search mode, the remote control will send IR codes from the library starting from the lowest code set number to the end of code set for that device; OR

- b. Press the “**CH DOWN**” key to start searching downward at approximately 5 second intervals for each code set. The TV/AUX mode key will be on and blink every 5 seconds while in the device scan mode.



**NOTE:** In this search mode, the remote control will send IR codes from the highest code set number to the beginning of code set of that device.

5. If the device turns off, a working code has been found. Press “**OK**” once to lock in the code. The selected mode key will blink twice
6. If all code sets of that device are exhausted in the search and the “**OK**” is not pressed, the selected device key will blink rapidly 7 times and the search mode will be terminated.



**NOTE:** During the auto-scan, you can press “**UP**” arrow or “**DOWN**” arrow to advance to the next device code immediately without waiting for 5 seconds. You can also use “**UP**” arrow or “**DOWN**” arrow to change the direction of the search. In the programming mode if no key is received within 30 seconds, the device mode key backlight will blink rapidly 7 times to indicate an error and then extinguish, and the programming mode will end.



# Step 1 - Connecting Video

## HDTV (High-Definition)

Select only one Video option and then proceed to TV Source

### OPTION #1 (Recommended)

#### Connect to HDMI

(HDMI cable included)



**HDMI®**  
HIGH-DEFINITION MULTIMEDIA INTERFACE

Connects both Video & Audio  
to deliver best entertainment  
experience with a single cable



HDTV

HDMI Cable  
(For HD Video)



CM-7400 Back

\*This connection handles both Video and Multi-Channel Audio. If you have selected HDMI for your Video, then proceed to page 15.

CM-7400



## OPTION #2

### Connect to Component Video\*

(\*Component Video cable not included)




Component  
Video Cable

Delivers excellent picture  
quality



HDTV

Component  
Video Cable



CM-7400 Back

# Step 1 - Continued

## SDTV (Standard-Definition)

Select only one Video option and then proceed to TV Source

### OPTION #3

#### Connect to Composite Video

(Composite Video cable included)




Composite  
Video

Delivers good picture quality



SDTV

Composite Video Cable  
(Please use Yellow Connector for  
Video Connection)



CM-7400 Back

CM-7400


## OPTION #4

### Connect to Coaxial

(Coaxial cable included)




Coaxial Cable  
Delivers good picture quality



SDTV

Coaxial Cable



CM-7400 Back

# Step 2 - Connecting TV Source

ATSC Antenna or Clear QAM Cable TV

Select only one TV Source option and then proceed to Audio

## OPTION #1

### Connect to Outdoor or Indoor Antenna Source (ATSC Antenna)

(Coaxial cable included)



HD Indoor  
Antenna

(Outdoor or indoor antenna  
sold separately)

Coaxial Cable




CM-7400 Back

CM-7400


## OPTION #2

### Connect to Clear QAM Cable TV Source using RF Coaxial Cable

(Coaxial cable included)



Clear QAM Cable TV



Coaxial Cable



CM-7400 Back

# Step 3 - Connecting Audio

TV (Stereo) or A/V Receiver (Surround Sound)

Select only one Audio option and then proceed to Networking

## OPTION #1


### Connect to TV's Stereo Audio

(Composite Video cable included)



HDTV

**Composite Video Cable**  
 (Use Red/White Connectors for Audio Connection if you've selected Component Video, or Composite Video)



CM-7400 Back


CM-7400



## OPTION #2

### Connect to A/V Receiver for Digital 5.1 Surround Sound\*

(\*Digital Audio cable not included)



A/V Receiver

Digital Audio Cable

CM-7400 Back

# Step 4 - Connecting Network


Wired or Wireless

Select only one Networking option and then proceed to Powering Up

## OPTION #1 (Recommended)

Connect to Wired Network via DSL, Cable Modem or Network Router\*

(\*Ethernet cable not included)



Router\*

(\*Router not included)

Ethernet  
Cable

CM-7400 Back

CM-7400




## OPTION #2

Connect to Wireless Network via Wireless Network Router or Access Point



Wireless Router\*

(\*Wireless Router  
not included)



CM-7400 Back

# Step 5 - Powering Up

## Setting up Remote Control

Put remote together and then proceed to connecting to a power source


1. Locate the AA batteries and remote in the accessory box.
2. Open battery cover by pressing down on battery cover latch and sliding cover off.
3. Insert the AA batteries, matching the "+" and "-" marks on the batteries to the "+" and "-" marks on the interior of the remote.
4. Snap the battery cover back onto the remote.



CM-7400 Remote back

## Connecting to Power Source

1. Connect the power connector from adapter to "POWER" in on your Channel Master TV product.
2. Connect AC adapter to power outlet.
3. Press power button to turn unit ON and follow on-screen directions.



CM-7400 Back

# Appendix - Device Codes

Your Universal Remote Control can control many brands and models of televisions, VCR's, DVD's and other types of audio-visual equipment. The following pages list device codes for many categories and brands of equipment. Many brands list more than one code, and you may need to test several codes to find the best match for your equipment. Your equipment may be supported even if your brand is not shown in the list below. If you cannot locate your brand, or none of the listed device codes work, then you may still use the Auto-Search feature to try to locate a suitable device code (see page 10).

## TV

### DIGITAL TV

Samsung 0163  
Zenith 0165

### HD PLASMA DISPLAY

RCA 0242, 0262

### HDTV

Apex 0083  
Daewoo 0267, 0333, 0419, 0336  
Hitachi 0091  
ILO 0094  
JVC 0071  
Mitsubishi 0111, 0238, 0013, 0147  
Panasonic 0311, 0012  
Philips 0192, 0303, 0000, 0244  
Proscan 0138  
RCA 0138, 0158, 0140, 0262  
Sampo 0055  
Sharp 0198  
Sony 0236, 0035, 0043, 0231  
Zenith 0103, 0105

### HDTV MONITOR

Brilliant 0184  
Panasonic 0161  
Philips 0217  
RCA 0282  
Sears 0184

### HDTV PROJECTION MONITOR

Panasonic 0215, 0299, 0310

Pioneer 0010, 0058  
Zenith 0091

### HDTV PROJECTION TV

Panasonic 0196  
Sony 0236

### LCD HDTV

Akai 0108  
ILO 0059  
Olevia 0142  
Polaroid 0212  
Syntax 0142  
Westinghouse 0021  
Zenith 0018

### LCD PROJECTION TV

Epson 0247  
LG 0207  
Panasonic 0033  
Sony 0243, 0053, 0292

### LCD TV

Akai 0270  
AOC 0275  
Audiovox 0205, 0003, 0150  
Benq 0028  
Coby 0306, 0475, 0477, 0479, 0480, 0481, 0482, 0483, 0484, 0485  
Dell 0070, 0256, 0230, 0376, 0363, 0441  
Emerson 0115, 0442, 0333, 0334, 0331, 0330, 0419, 0391, 0450, 0457  
Emprex 0134, 0394  
Funai 0144  
Hisense 0109  
HP 0191

Initial 0271, 0458  
Insignia 0139

JVC 0251, 0101, 0194  
LG 0148, 0308, 0040, 0172

Magnavox 0044, 0271  
Maxent 0098

Mintek 0271, 0458  
Mitsubishi 0238  
NEC 0149

NET-TV 0197  
Norcent 0275  
Olevia 0168, 0414, 0365, 0369, 0385  
Panasonic 0253, 0038, 0285, 0117, 0291  
Philips 0034, 0112  
Polaroid 0130, 0089, 0078, 0281, 0167  
RCA 0242

Samsung 0187, 0166, 0234, 0177, 0057, 0093, 0283, 0296, 0180

Sansui 0199  
Sanyo 0031, 0298  
Sharp 0008, 0160, 0219, 0084, 0241, 0060, 0294, 0074

Sony 0243, 0155, 0035, 0126, 0090  
Sylvania 0144, 0115, 0284  
Syntax 0168, 0414, 0365, 0369, 0385

Tatung 0092  
Toshiba 0042, 0222, 0064  
Trutech 0206

Viewsonic 0021, 0085,  
0107, 0026, 0290, 0174,  
0082, 0277, 0255, 0069,  
0304

Vizio 0002

Westinghouse 0021, 0063,  
0054, 0424, 0333, 0359,  
0360, 0380, 0382, 0409

Zenith 0146

#### **LCD TV/PC MONITOR**

Sampo 0280

#### **LCD TV/TUNER COMBO**

Polaroid 0130

#### **PLASMA DISPLAY**

Acer 0229

Daewoo 0067

Fujitsu 0240

Funai 0250

Panasonic 0195

Pioneer 0203, 0077, 0065

Samsung 0171, 0118,  
0095, 0258

Toshiba 0099

Viewsonic 0156, 0106

Zenith 0183, 0214, 0226

#### **PLASMA TV**

Akai 0201

Elite 0213

Gateway 0269

Hewlett Packard 0123,  
0400, 0402

HP 0191, 0400, 0402

ILO 0237, 0421, 0458

LG 0133, 0172

Magnavox 0047, 0025

Panasonic 0033, 0104,  
0179

Pioneer 0213

Samsung 0166, 0254

Sanyo 0131

Sony 0155

SVA 0185, 0356, 0457

Viewsonic 0080

Vizio 0002

#### **PLASMA TV MONITOR**

Akai 0170

Fujitsu 0252, 0049, 0260,  
0186, 0257

Hitachi 0091, 0041, 0080,  
0314

Marantz 0224

NEC 0224

NET-TV 0004

Panasonic 0039

Pioneer 0208

Plasmsync 0224

Sony 0289, 0086

Toshiba 0224, 0120

Zenith 0011

#### **PROJECTION HDTV**

Sharp 0313, 0246

#### **PROJECTION TV**

Hitachi 0091, 0066, 0141,  
0100, 0020, 0261, 0235

JVC 0071, 0248

Magnavox 0202

Mitsubishi 0263, 0111,  
0238, 0013, 0147, 0073,  
0137

Panasonic 0033, 0196,  
0110

Philips 0132

Pioneer 0152

RCA 0138, 0158

Samsung 0007, 0300,  
0218, 0119

Sharp 0127

Sony 0243, 0178, 0135,  
0125

Toshiba 0307, 0159, 0081,  
0006

Zenith 0164

#### **TV - TV**

Admiral 0223, 0288, 0129,  
0326, 0334

Advent 0312, 0341

Adventura 0143

Aiwa 0124

Akai 0153, 0177, 0046,  
0287, 0347, 0420, 0339,  
0512, 0513, 0514, 0515

Alleron 0268

America Action 0097

Amtron 0182

Anam 0097

Anam National 0279, 0182

AOC 0239, 0308, 0390,  
0411, 0461, 0464

Apex 0249, 0264

Apex Digital 0227, 0329,  
0343, 0490

Audiovox 0182, 0097,  
0333, 0344, 0351, 0358,  
0381, 0448, 0454, 0455,  
0491

Aventura 0295, 0330

Axon 0448

Belcor 0308

Bell & Howell 0223, 0014

Benq 0079

Bradford 0182, 0097

Brockwood 0308

Broksonic 0097, 0288,  
0032, 0046, 0199, 0334

Candle 0143, 0308

Carver 0325

Celebrity 0153, 0322

Celera 0227

Changhong 0227

Citizen 0182, 0221, 0308,  
0061

Clarion 0097

Colortyme 0308

Commercial Solutions  
0396, 0323

Concerto 0308

Contec 0097

Contec/Cony 0182

Craig 0182, 0097

Crosley 0122, 0322, 0325

Crown 0182, 0097

CTX 0027

Curtis 0486, 0496

Curtis Mathes 0017, 0014,  
0221, 0122, 0209, 0308,  
0129, 0323, 0325, 0333,  
0326, 0339, 0327, 0419,  
0367, 0386

CXC 0182, 0097

Cytron 0051, 0220

Daewoo 0239, 0062, 0274,  
0308, 0061

Daytron 0308

Denon 0209, 0327

Diamond Vision 0045,  
0216, 0188

Dimensia 0017

Dish Network System  
0453

Dumont 0286, 0308

Durabrand 0048, 0295,  
0097, 0288, 0334, 0331,  
0330

Dwin 0129

Dynex 0435, 0437, 0439,  
0462, 0470

Electroband 0153, 0322

Electrograph 0228, 0430

Electrohome 0153, 0279,  
0308, 0334

Element 0469

Emerson 0182, 0268,

0014, 0295, 0097, 0288, 0062, 0032, 0162, 0308, 0276, 0061	JVC 0102, 0175, 0297, 0259, 0096, 0121, 0334, 0324, 0335, 0340, 0372, 0413, 0434, 0474	NetTV 0430
Envision 0308, 0348, 0390, 0411, 0461, 0464	Kawasho 0153, 0308	Net-TV 0228
Epson 0301	KDS 0401	Nexus Electronics 0469
ESA 0295, 0177, 0347, 0330, 0450, 0457	KEC 0097	Nikko 0331
Fisher 0014	Kenwood 0308	Norcent 0116, 0390, 0411
Fujitsu 0268, 0345	KLH 0227, 0343	Onwa 0182, 0097
Funai 0182, 0268, 0295, 0097, 0169, 0322, 0330, 0378, 0457	Kloss Novabeam 0182, 0143	Optimus 0075, 0332, 0335
Futuretech 0182, 0097	KTV 0182, 0097	Optoma 0387
Gateway 0228, 0173, 0430, 0431	Lemon 0510	Optonica 0225, 0129, 0326
GE 0017, 0279, 0309, 0138, 0308, 0245, 0087, 0396, 0323, 0333, 0331, 0386	LG 0239, 0395, 0377, 0331, 0353, 0488, 0494, 0508	Orion 0288, 0001, 0032, 0334
GFM 0330, 0457	Lloyd's 0169	Panasonic 0279, 0056, 0036, 0196, 0190, 0176, 0029, 0075, 0399, 0332, 0398, 0335, 0378, 0449, 0452, 0509
Goldstar 0239, 0308, 0030, 0331	Logik 0223	PARK 0466
Grunpy 0182, 0268, 0097	Luxman 0308	Penney 0245, 0030, 0323, 0329, 0331, 0386
Haier 0048, 0427, 0428, 0429, 0476	LXI 0017, 0014, 0122, 0323, 0325, 0329, 0331	Petters 0405
Hallmark 0308, 0331	MAG 0401	Philco 0279, 0239, 0122, 0050, 0308, 0325, 0330, 0378, 0391, 0457
Hannspree 0387, 0426, 0498	Magnasonic 0061	Philips 0279, 0122, 0068, 0128, 0114, 0016, 0308, 0397, 0444, 0325, 0338, 0445, 0489
Harley Davidson 0169	Magnavox 0122, 0022, 0009, 0308, 0276, 0169, 0397, 0444, 0325, 0344, 0373, 0390, 0450, 0457, 0458, 0489	Philips Magnavox 0068, 0022, 0114
Harman/Kardon 0122, 0325	Magnin 0245	Pilot 0308
Harvard 0182, 0097	Majestic 0223	Pioneer 0308, 0398, 0337, 0357, 0375
Havermy 0129, 0326	Marantz 0122, 0308, 0397, 0325	Polaroid 0227, 0204, 0405, 0356, 0379, 0383, 0401, 0433, 0459, 0467
Helios 0356	Matsushita 0332, 0335	Portland 0239, 0308, 0333, 0419
Hello Kitty 0333	Maxent 0228, 0430	Price Club 0221
Hisense 0116, 0383, 0465, 0487, 0493	Megatron 0209, 0331, 0327	Prima 0312, 0341, 0437
Hitachi 0209, 0091, 0273, 0308, 0169, 0417, 0366, 0327	Memorex 0223, 0239, 0014, 0288, 0144, 0019, 0075, 0030, 0334, 0328, 0331, 0447	Proscan 0017, 0138, 0396, 0323, 0386, 0468, 0473
Ilo 0271	MGA 0239, 0308, 0245, 0328, 0331	Proton 0308, 0331
IMA 0182	Midland 0286, 0323	Proview 0401
Infinity 0122, 0325	Mitsubishi 0239, 0263, 0308, 0129, 0087, 0371, 0326, 0328, 0331	Pulsar 0286, 0308
Insignia 0001, 0278, 0211, 0395, 0408, 0330, 0403, 0435, 0447, 0457, 0459, 0462, 0492	Montgomery Ward 0223	Quasar 0279, 0075, 0332, 0335
Janeil 0143	Motorola 0279, 0129, 0326	Radio Shack 0014, 0097, 0169
JBL 0122, 0325	MTC 0239, 0221, 0308	Radio Shack/Realistic 0017, 0182, 0014, 0225, 0308
JC Penney 0017, 0239, 0221, 0308	Multitech 0182, 0097	RadioShack 0323, 0331
JCB 0153, 0322	NAD 0329, 0331, 0357, 0368	RCA 0017, 0279, 0239,
Jensen 0308, 0341	NEC 0279, 0239, 0308, 0422, 0438	

0266, 0138, 0157, 0242,  
0023, 0308, 0005, 0262,  
0245, 0087, 0407, 0396,  
0323, 0326, 0337, 0361,  
0367, 0370, 0386, 0436,  
0453, 0456, 0459, 0471,  
0472  
Realistic 0014, 0097, 0331  
Runco 0286  
Sampo 0228, 0265, 0308,  
0430  
Samsung 0239, 0221,  
0232, 0233, 0177, 0193,  
0308, 0347, 0339, 0331,  
0335, 0342, 0362, 0463,  
0503  
Sansui 0288, 0316, 0001,  
0032, 0046, 0199, 0169,  
0334, 0330, 0393, 0447  
Sanyo 0014, 0308, 0245,  
0325, 0364  
Sceptre 0389, 0412  
Scotch 0331  
Scott 0182, 0268, 0097,  
0308, 0331, 0423  
Sears 0017, 0268, 0014,  
0145, 0122, 0295, 0308,  
0169, 0030, 0323, 0325,  
0329, 0331, 0330  
Sharp 0225, 0308, 0113,  
0129, 0349, 0326, 0504,  
0505  
Sheng Chia 0129, 0326  
Sherwood 0392  
Shogun 0308  
Signature 0223  
Sky 0507  
Sony 0153, 0243, 0072,  
0154, 0302, 0305, 0037,  
0169, 0346, 0322, 0506  
Soundesign 0182, 0268,  
0097, 0308, 0331  
Sova 0455  
Soyo 0404, 0440  
Spectroniq 0401  
Squareview 0145, 0295,  
0330  
SSS 0182, 0097, 0308  
Starlite 0182, 0097  
SunBrite 0478  
Superscan 0276, 0129,  
0326, 0355, 0450  
Supre-Macy 0143  
Supreme 0153, 0322  
Sylvania 0122, 0295,  
0024, 0315, 0308, 0276,  
0442, 0325, 0330, 0378,  
0383, 0391, 0446, 0450,  
0457, 0497  
Symphonic 0182, 0145,  
0295, 0097, 0272, 0169,  
0330, 0450  
Tandy 0129, 0326  
Tatung 0279, 0173, 0431  
Technics 0332  
Techview 0352  
Techwood 0308  
Teknika 0223, 0239, 0182,  
0268, 0221, 0122, 0097,  
0308, 0325, 0328  
Telefunken 0339  
Tevion 0511  
Thomas 0169  
TMK 0308, 0331  
Toshiba 0014, 0221, 0200,  
0136, 0015, 0293, 0189,  
0046, 0052, 0210, 0151,  
0321, 0406, 0329, 0374,  
0377, 0335, 0350, 0368,  
0388, 0418, 0422, 0451,  
0460, 0499  
TVS 0288, 0334  
Venturer 0443  
Victor 0324  
Vidikron 0122, 0325  
Vidtech 0239, 0308, 0331  
Viewsonic 0228, 0430,  
0354, 0355, 0359, 0384,  
0410, 0415, 0416, 0425,  
0461, 0464  
Viking 0143  
Viore 0421, 0466, 0486  
Vizio 0173, 0432, 0355,  
0359, 0431, 0500, 0501,  
0502  
Wards 0017, 0223, 0239,  
0268, 0225, 0122, 0308,  
0325, 0331, 0357, 0368  
Waycon 0329  
White Westinghouse 0288,  
0062, 0334, 0419  
Wyse 0390  
Yamaha 0239, 0308  
Zenith 0223, 0288, 0286,  
0088, 0032, 0308, 0169,  
0322, 0395, 0323, 0334,  
0377, 0331, 0366, 0327,  
0419

---

**TV MONITOR**


---

Sony 0181

---

**TV/DVD/TUNER COMBO**


---

Panasonic 0176

Sony 0126

---

**TV/DVD/VCR/TUNER**


---



---

**COMBO**


---

Polaroid 0281

---

**TV/TUNER**


---

Audiovox 0205, 0003

---

**TV/VCR COMBO**


---

Broksonic 0032

Citizen 0061

Colt 0076

Daewoo 0061

Emerson 0032, 0061

Funai 0169

GE 0245, 0087

Goldstar 0030

Harley Davidson 0169

Hitachi 0169

Lloyd's 0169

Magnasonic 0061

Magnavox 0169

Magnin 0245

Memorex 0075, 0030

MGA 0245

Mitsubishi 0087

Optimus 0075

Orion 0032

Panasonic 0075

Penney 0245, 0030

Quasar 0075

RadioShack 0169

RCA 0245, 0087

Sansui 0032, 0169

Sanyo 0245

Sears 0169, 0030

Sony 0169

Symphonic 0169

Thomas 0169

Zenith 0032, 0169

---

**TV/DVD COMBO**


---

Aiwa 0124

Akai 0046, 0270

Apex 0264

Audiovox 0150

Broksonic 0046, 0199

Coby 0306

Cytron 0220

Diamond Vision 0216

Emerson 0162

Ilo 0271

Initial 0271

JVC 0121  
 LG 0308, 0040  
 Magnavox 0271  
 Mintek 0271  
 Panasonic 0190  
 Philips 0016, 0271  
 RCA 0023  
 Samsung 0193  
 Sansui 0046, 0199, 0199  
 Sylvania 0315, 0284  
 Toshiba 0046, 0052, 0210

### **TV/DVD/VCR COMBO**

Akai 0287  
 Diamond Vision 0188  
 Emerson 0276  
 Magnavox 0276  
 Memorex 0019  
 Panasonic 0029  
 Polaroid 0204  
 RCA 0005  
 Samsung 0193  
 Sharp 0113  
 Superscan 0276  
 Sylvania 0276  
 Toshiba 0151

## **DVD**

### **DVD - DVD**

Advent 4234  
 Aiwa 4077  
 Akai 4093, 4088, 4129, 4199  
 Alco 4118  
 Alpine 4040  
 Amphion MediaWorks 4023  
 AMW 4023  
 Apex 4201, 4074, 4124  
 Apex Digital 4111  
 Aspire Digital 4246  
 Audiovox 4118, 4229, 4041, 4022  
 Blaupunkt 4111, 4188  
 Blue Parade 4117  
 BOSE 4095, 4235  
 Broksonic 4093, 4088, 4173  
 California Audio Labs 4017  
 CambridgeSoundWorks 4144  
 Clarion 4242  
 Classic 4218, 4140  
 Coby 4243, 4149, 4089, 4147

CyberHome 4107  
 Cytron 4116  
 Daewoo 4035, 4067  
 Denon 4017, 4222, 4054, 4037, 4090, 4047  
 Desay 4176  
 Diamond Vision 4158, 4075, 4014  
 Disney 4049  
 Emerson 4165, 4049, 4181, 4208, 4030, 4206, 4079  
 ESA 4167  
 Fisher 4065  
 Funai 4049, 4181, 4208  
 GE 4224, 4111  
 Go Video 4072  
 Goldstar 4162  
 GPX 4220  
 Gradiente 4017  
 Greenhill 4111  
 Grundig 4085  
 Harman/Kardon 4244  
 Hitachi 4180, 4156, 4028  
 Ilo 4066  
 Initial 4111, 4060  
 Insignia 4121  
 Integra 4209, 4117  
 JBL 4221  
 Jensen 4149  
 JVC 4152, 4006, 4212, 4056, 4245, 4186, 4123, 4064, 4195  
 Kawasaki 4118  
 Kenwood 4017, 4031  
 KLH 4118, 4111, 4214  
 Konka 4010  
 Koss 4002, 4011, 4052, 4099, 4239  
 Lasonic 4210  
 Lenox 4061  
 LG 4105, 4223, 4029  
 Liquid Video 4011  
 Magnavox 4165, 4198, 4085, 4049, 4050, 4060  
 Marantz 4085, 4168, 4193  
 Memorex 4093, 4225, 4012  
 Microsoft 4224  
 Mintek 4111, 4237, 4060  
 Mitsubishi 4207, 4155  
 NAD 4157  
 Nakamichi 4191  
 Nesa 4111

Norcent 4243, 4083, 4073, 4232  
 Onkyo 4209, 4198, 4027, 4062, 4159, 4133, 4058  
 Oritron 4002, 4011  
 Panasonic 4017, 4198, 4120, 4081, 4222, 4091, 4200, 4038, 4143, 4080, 4044, 4013  
 Philips 4198, 4085, 4049, 4019, 4070, 4208, 4247, 4078, 4009, 4161  
 Pioneer 4163, 4117, 4153, 4194, 4130, 4119  
 Polaroid 4230, 4016, 4069, 4102  
 Polk Audio 4085  
 Presidian 4049, 4208  
 Proscan 4224, 4226  
 Qwestar 4002  
 RCA 4118, 4224, 4117, 4111, 4007, 4226, 4042, 4086, 4185, 4160  
 Regent 4061  
 Rotel 4152  
 Rowa 4092  
 Sampo 4182  
 Samsung 4017, 4180, 4032, 4051, 4082, 4241, 4135, 4146  
 Sansui 4093, 4088, 4173, 4251  
 Sanyo 4093, 4132, 4213  
 Sharp 4049, 4204, 4131, 4202, 4115  
 Sherwood 4177, 4203  
 Shinco 4008  
 Shinsonic 4205  
 Sony 4205, 4216, 4174, 4045, 4169, 4166, 4189, 4240, 4094, 4211, 4154, 4048, 4127, 4142, 4249, 4217  
 Sungale 4228  
 Superscan 4165  
 Sylvania 4165, 4049, 4181, 4208, 4187, 4112, 4001  
 Symphonic 4049, 4104, 4208  
 Teac 4118, 4015  
 Technics 4017, 4222  
 Techwood 4137  
 Theta Digital 4117



Toshiba 4093, 4198, 4184,  
4071, 4088, 4024, 4173,  
4175, 4100  
Trutech 4059  
Urban Concepts 4198  
Venturer 4118, 4036  
Xbox 4224  
Yamaha 4017, 4085, 4106,  
4101  
Zenith 4198, 4025, 4021

### **DVD RECORDER**

Apex 4097  
Broksonic 4026  
Gateway 4190  
Go Video 4190  
Hitachi 4150, 4171  
Insignia 4145  
Irradio 4126  
JVC 4046, 4000, 4057,  
4003, 4164, 4179, 4227,  
4098  
LG 4148, 4076, 4170  
LiteON 4248, 4238, 4215,  
4005  
Lite-On 4190  
Panasonic 4084, 4043,  
4151, 4039  
Philips 4250, 4192, 4231,  
4053  
Pioneer 4068, 4138  
RCA 4219  
Samsung 4150, 4136,  
4178  
Sansui 4063  
Sanyo 4034  
Sensory Science 4190  
Sharp 4096, 4108, 4087,  
4109  
Sony 4183  
Sylvania 4233, 4033  
Toshiba 4020, 4236, 4114  
Yamaha 4139  
Zenith 4018, 4122, 4170

### **DVR**

JVC 4004, 4113, 4128,  
4196  
Pioneer 4055  
RCA 4103  
Toshiba 4125, 4110, 4134

### **DVR/VCR COMBO**

JVC 4004, 4113, 4128,  
4196

### **TV/DVD/TUNER COMBO**

Panasonic 4143

Polaroid 4069  
Sony 4127

### **TV/DVD COMBO**

Aiwa 4077  
Akai 4088, 4129  
Apex 4124  
Audiovox 4229  
Broksonic 4088, 4173  
Coby 4089  
Cytron 4116  
Diamond Vision 4075  
Emerson 4206  
Ilo 4066  
Initial 4060  
JVC 4186  
LG 4223, 4029  
Magnavox 4060  
Mintek 4060  
Panasonic 4038  
Philips 4078, 4060  
RCA 4086  
Samsung 4082  
Sansui 4088, 4173, 4251  
Sylvania 4112, 4001  
Toshiba 4088, 4024, 4173

### **TV/DVD/VCR COMBO**

Akai 4199  
Diamond Vision 4014  
Emerson 4165  
Magnavox 4165  
Memorex 4012  
Panasonic 4080  
Polaroid 4102  
RCA 4185  
Samsung 4241  
Sharp 4202  
Superscan 4165  
Sylvania 4165  
Toshiba 4175

### **DVD/VCR COMBO**

Broksonic 4093, 4026,  
4173  
Daewoo 4067  
Emerson 4208, 4030  
Funai 4208  
Go Video 4072  
Goldstar 4162  
Hitachi 4171, 4028  
Insignia 4145  
JVC 4000, 4245, 4057,  
4003, 4164  
LG 4148, 4076, 4170,  
4105  
Magnavox 4050

Memorex 4093  
Panasonic 4200  
Philips 4208, 4247  
Pioneer 4138  
Polaroid 4016  
Presidian 4208  
RCA 4042  
Samsung 4051  
Sansui 4093, 4063  
Sanyo 4132  
Sharp 4108, 4087, 4131  
Sony 4154, 4048  
Sylvania 4208, 4187  
Symphonic 4208  
Toshiba 4114, 4071  
Zenith 4170, 4021

### **HTIB**

Audiovox 4041, 4022  
BOSE 4235  
CambridgeSoundWorks  
4144  
Classic 4140  
Coby 4147  
Denon 4047  
Emerson 4079  
Insignia 4121  
JBL 4221  
JVC 4123, 4064, 4195  
Koss 4099, 4239  
Onkyo 4159, 4133, 4058  
Panasonic 4044, 4013,  
4197  
Philips 4009, 4161  
Pioneer 4194, 4130, 4119  
RCA 4219  
Samsung 4135, 4146  
Sanyo 4213  
Sharp 4115  
Sherwood 4203  
Sony 4172, 4142, 4249,  
4217, 4141  
Toshiba 4100  
Venturer 4036  
Yamaha 4106, 4101

### **DVR/VCR COMBO**

JVC 3017, 3071, 3054,  
3080

## **VCR**

### **VCR - VCR**

ABS 3053  
Adventura 3062  
Aiwa 3062  
Akai 3068, 3039

- Alienware 3053  
 American High 3021  
 Asha 3052  
 Audio Dynamics 3024  
 Audiovox 3043  
 Beaumark 3052  
 Bell & Howell 3083  
 Broksonic 3051, 3067,  
     3060, 3022  
 Calix 3043  
 Candle 3052, 3043  
 Canon 3021  
 Citizen 3052, 3043, 3097  
 Colortyme 3024  
 Colt 3008  
 Craig 3052, 3043  
 Curtis Mathes 3020, 3024,  
     3052, 3021, 3011  
 Cybernex 3052  
 Cyperpower 3053  
 Daewoo 3062, 3010, 3055,  
     3097  
 DBX 3024  
 Dell 3053  
 Diamond Vision 3058  
 Dimensia 3020, 3011  
 Durabrand 3073  
 Dynatech 3062  
 Electrohome 3043  
 Electrophonic 3043  
 Emerson 3043, 3021,  
     3062, 3063, 3049, 3003,  
     3097, 3022  
 ESA 3007  
 Fisher 3083, 3050, 3087  
 Fuji 3068, 3021  
 Funai 3062, 3037, 3063,  
     3091  
 Garrard 3062  
 Gateway 3053  
 GE 3020, 3052, 3021,  
     3011, 3069, 3019  
 Go Video 3027  
 Goldstar 3024, 3043,  
     3064, 3001  
 Gradiente 3062  
 Harley Davidson 3062,  
     3091  
 Harman/Kardon 3024  
 Headquarter 3083  
 Hewlett Packard 3053  
 Hitachi 3066, 3014, 3091  
 Howard Computers 3053  
 HP 3053  
 Hush 3053  
 iBUYPOWER 3053  
 Insignia 3082  
 Instant Replay 3021  
 JC Penney 3024, 3083,  
     3052, 3043, 3021  
 JCL 3021  
 JVC 3024, 3083, 3098,  
     3044, 3041, 3089, 3028,  
     3017, 3025, 3034, 3071,  
     3046, 3054, 3094, 3030  
 Kenwood 3024, 3083  
 Kodak 3043, 3021  
 LG 3043, 3075, 3082,  
     3081  
 Linksys 3053  
 Lloyd's 3062, 3091  
 LXI 3043  
 Magnasonic 3097  
 Magnavox 3021, 3073,  
     3013, 3085, 3003, 3091  
 Magnin 3043, 3069  
 Marantz 3024, 3083, 3021  
 Marta 3043  
 Matsushita 3021  
 Media Center PC 3053  
 MEI 3021  
 Memorex 3083, 3052,  
     3043, 3021, 3062, 3073,  
     3038, 3090, 3067, 3009,  
     3092, 3001  
 MGA 3069  
 MGN Technology 3052  
 Microsoft 3053  
 Mind 3053  
 Mitsubishi 3031, 3019  
 Motorola 3021  
 MTC 3052  
 Multitech 3052, 3062  
 NEC 3024, 3083  
 Nikko 3043  
 Niveus Media 3053  
 Noblex 3052  
 Northgate 3053  
 Olympus 3021  
 Optimus 3043, 3092  
 Orion 3038, 3022  
 Panasonic 3021, 3040,  
     3023, 3096, 3070, 3076,  
     3092  
 Penney 3069, 3001  
 Philco 3021  
 Philips 3021, 3013, 3063,  
     3074  
 Philips Magnavox 3013  
 Pilot 3043  
 Pioneer 3002  
 Polaroid 3059, 3077  
 Presidian 3063  
 Proscan 3020, 3011, 3016  
 Pulsar 3073  
 Quarter 3083  
 Quartz 3083  
 Quasar 3021, 3092  
 Radio Shack 3043, 3091  
 Radio Shack/Realistic  
     3083, 3052, 3043, 3021,  
     3062  
 Radix 3043  
 Randex 3043  
 RCA 3020, 3052, 3021,  
     3011, 3088, 3035, 3000,  
     3079, 3069, 3019  
 Realistic 3083, 3052,  
     3043, 3021, 3062  
 Ricavision 3053  
 Ricoh 3026  
 Runco 3073  
 Samsung 3052, 3048,  
     3012  
 Sanky 3073  
 Sansui 3038, 3047, 3067,  
     3091, 3022  
 Sanyo 3083, 3052, 3050,  
     3087, 3093, 3069  
 Sears 3083, 3043, 3021,  
     3091, 3001  
 Sharp 3084, 3065, 3086,  
     3078, 3015, 3056, 3018  
 Shintom 3068  
 Shogun 3052  
 Singer 3021, 3026  
 Sony 3068, 3042, 3053,  
     3005, 3033, 3004, 3072,  
     3029, 3091  
 Stack 3053  
 Superscan 3003  
 Sylvania 3021, 3062,  
     3063, 3032, 3003  
 Symphonic 3062, 3037,  
     3063, 3091  
 Systemax 3053  
 Tagar Systems 3053  
 Tandy 3083  
 Tashiko 3043  
 Teac 3062  
 Technics 3021  
 Teknika 3043, 3021, 3062

Thomas 3091  
 TMK 3052  
 Toshiba 3053, 3057, 3095,  
 3006, 3045, 3036  
 Totevision 3052, 3043  
 Touch 3053  
 Unitech 3052  
 Vector Research 3024  
 Video Concepts 3024  
 Videosonic 3052  
 Viewsonic 3053  
 Voodoo 3053  
 Wards 3052, 3043, 3021,  
 3062  
 White Westinghouse 3037  
 XR-1000 3021, 3062  
 Yamaha 3024, 3083  
 Zenith 3068, 3026, 3073,  
 3061, 3082, 3099, 3091,  
 3022  
 ZT Group 3053

#### **TV/VCR COMBO**

Broksonic 3022  
 Citizen 3097  
 Colt 3008  
 Daewoo 3097  
 Emerson 3097, 3022  
 Funai 3091  
 GE 3069, 3019  
 Goldstar 3001  
 Harley Davidson 3091  
 Hitachi 3091  
 Lloyd's 3091  
 Magnasonic 3097  
 Magnavox 3091  
 Magnin 3069  
 Memorex 3092, 3001  
 MGA 3069  
 Mitsubishi 3019  
 Optimus 3092  
 Orion 3022  
 Panasonic 3092  
 Penney 3069, 3001  
 Quasar 3092  
 RadioShack 3091  
 RCA 3069, 3019  
 Sansui 3091, 3022  
 Sanyo 3069  
 Sears 3091, 3001  
 Sony 3091  
 Symphonic 3091  
 Thomas 3091  
 Zenith 3091, 3022

#### **TV/DVD/VCR COMBO**

Akai 3039  
 Diamond Vision 3058  
 Emerson 3003  
 Magnavox 3003  
 Memorex 3009  
 Panasonic 3076  
 Polaroid 3077  
 RCA 3079  
 Samsung 3012  
 Sharp 3018  
 Superscan 3003  
 Sylvania 3003  
 Toshiba 3036

#### **DVD/VCR COMBO**

Broksonic 3051, 3067,  
 3060  
 Daewoo 3055  
 Emerson 3063, 3049  
 Funai 3063  
 Go Video 3027  
 Goldstar 3064  
 Hitachi 3066, 3014  
 Insignia 3082  
 JVC 3028, 3025, 3034,  
 3046, 3030  
 LG 3075, 3075, 3082,  
 3081  
 Magnavox 3085  
 Memorex 3067  
 Panasonic 3070  
 Philips 3063, 3074  
 Pioneer 3002  
 Polaroid 3059  
 Presidian 3063  
 RCA 3000  
 Samsung 3048  
 Sansui 3067, 3047  
 Sanyo 3093  
 Sharp 3015, 3078, 3056  
 Sony 3072, 3029  
 Sylvania 3063, 3032  
 Symphonic 3063  
 Toshiba 3006, 3045  
 Zenith 3082, 3099

## **AUDIO**

#### **AMPLIFIER**

Denon 2041  
 JBL 2090  
 Krell 2068  
 Magnavox 2013  
 Marantz 2098  
 Parasound 2034, 2103

Pioneer 2070, 2031  
 RCA 2010  
 Rotel 2011  
 Soundmatters 2039  
 Technics 2008  
 Yamaha 2079, 2026

#### **AUDIO CASSETTE**

Curtis Mathes 2070  
 Magnavox 2013  
 Marantz 2008, 2013  
 Optimus 2070  
 Pioneer 2070  
 Technics 2008

#### **AUDIO SYSTEM**

Curtis Mathes 2070  
 Pioneer 2070

#### **LCD TV/TUNER COMBO**

Polaroid 2028

#### **PHONO**

Magnavox 2013  
 Marantz 2013  
 Pioneer 2070

#### **RECEIVER**

JBL 2020  
 Sanyo 2071

#### **RECEIVER/AMPLIFIER**

Yamaha 2026

#### **RECEIVER/TUNER**

Adcom 2078  
 Aiwa 2085, 2037, 2093  
 Audiovox 2077, 2036  
 BOSE 2060, 2032  
 CambridgeSoundWorks  
 2053  
 Carver 2085  
 Classic 2009  
 Coby 2045  
 Curtis Mathes 2070  
 Denon 2023, 2091, 2016  
 Emerson 2014  
 Harman/Kardon 2085,  
 2052, 2094  
 Insignia 2082, 2063, 2038  
 JBL 2020  
 JVC 2097, 2073, 2029,  
 2006, 2000, 2024  
 Kenwood 2019, 2072,  
 2044, 2089, 2099, 2012  
 Linn 2085  
 Magnavox 2013, 2085  
 Marantz 2008, 2013, 2085,  
 2056  
 Mitsubishi 2080  
 NAD 2095

Nakamichi 2033  
 Onkyo 2067, 2017, 2002,  
 2057, 2100, 2065  
 Optimus 2070, 2054  
 Panasonic 2008, 2088,  
 2058, 2007, 2051, 2066  
 Philips 2085, 2096, 2047  
 Pioneer 2070, 2048, 2062,  
 2074, 2030, 2027, 2022,  
 2049  
 Polk Audio 2050  
 Quasar 2008  
 RCA 2059  
 Rotel 2011  
 Samsung 2064, 2021  
 Sansui 2085  
 Sharp 2001  
 Sherwood 2046, 2015  
 Sony 2086, 2081, 2092,  
 2061, 2083, 2069, 2101,  
 2025  
 Technics 2008, 2088, 2058  
 Toshiba 2084  
 Wards 2085  
 Yamaha 2075, 2003, 2040,  
 2076

---

**TUNER**


---

Aiwa 2043  
 Audiovox 2087  
 Koss 2018  
 Panasonic 2007, 2004,  
 2042  
 Polaroid 2028, 2035  
 Sony 2055, 2025  
 Venturer 2036

---

**TUNER/CD COMBO**


---

Aiwa 2043  
 BOSE 2060  
 Panasonic 2042

---

**TV/DVD/TUNER COMBO**


---

Panasonic 2004  
 Polaroid 2035  
 Sony 2055

---

**TV/TUNER**


---

Audiovox 2087

---

**TV/VCR/TUNER COMBO**


---

Panasonic 2007

---

**HTIB**


---

Audiovox 2077, 2036  
 BOSE 2032  
 CambridgeSoundWorks  
 2053  
 Classic 2009  
 Coby 2045

Denon 2016  
 Emerson 2014  
 Insignia 2038  
 JBL 2020  
 JVC 2006, 2000, 2024  
 Koss 2018, 2018  
 Onkyo 2057, 2100, 2065  
 Panasonic 2051, 2066,  
 2102  
 Philips 2096, 2047  
 Pioneer 2027, 2022, 2049  
 RCA 2059  
 Samsung 2064, 2021  
 Sanyo 2071  
 Sharp 2001  
 Sherwood 2015  
 Sony 2101, 2025, 2025,  
 2025, 2005  
 Toshiba 2084  
 Venturer 2036  
 Yamaha 2040, 2076

## CD

---

**CD - CD**


---

ADC 4274  
 Aiwa 4272  
 BOSE 4269  
 Denon 4273  
 Harman Kardon 4270  
 JVC 4261, 4259  
 Kenwood 4263  
 Marantz 4275  
 McIntosh 4265  
 Nakamichi 4271  
 Onkyo 4257, 4278  
 Panasonic 4254, 4264  
 Philips 4262  
 Pioneer 4255  
 RCA 4256  
 Sanyo 4258  
 Sherwood 4268  
 Sony 4276, 4266, 4252  
 Teac 4277  
 Technics 4267  
 Yamaha 4260

---

**CD/CD RECORDER**


---

Philips 4262

---

**TUNER/CD COMBO**


---

Aiwa 4272  
 BOSE 4269  
 Panasonic 4254

# Declaration of Conformity



To ensure proper use of this product, please read this manual carefully and retain it for future reference. Should the unit require maintenance, contact an authorized service location.



**WARNING:** This symbol indicates the presence of uninsulated dangerous voltage within the product's enclosure that constitutes a risk of electric shock. Do not open the product's case.



**CAUTION:** This symbol indicates you must take care; there is risk of damage to the equipment or to yourself.



To prevent fire or shock hazard, do not expose this product to rain or moisture. To reduce the risk of electric shock, DO NOT remove the cover or back. No user serviceable parts are inside. For servicing refer to qualified personnel.



## **Declaration of Conformity (United States Only)**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Federal Communication Commission (FCC) Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to a different circuit from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



## **Declaration of Conformity (Europe Only)**

This product is in conformity with the Council Directives:

- EMC Directive 2004/108/EC
- Low voltage Directive 2006/95/EC



## **Canada Certification Notice**

ICES-003 Class B Notice

This Class B digital apparatus complies with Canadian ICES-003.



Avis NMB-003, Classe B

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada

The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective operations and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The department does not guarantee the equipment will operate to the user's satisfaction. This equipment meets the applicable Industry Canada Terminal Equipment Technical Specification. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment. If you experience trouble with this equipment, do not try to repair the equipment yourself. The equipment cannot be repaired in the field and must be returned to the manufacturer. Repairs to certified equipment should be coordinated by a representative, and designated by the supplier.

# Product Return Policy & Warranty

## IN WARRANTY / OUT OF WARRANTY / CREDIT PROCEDURE EFFECTIVE IMMEDIATELY

### WARRANTY PERIOD:

Channel Master TV has a standard one (1) year limited warranty from the original purchase date. During the first ninety (90) days, your warranty covers both parts and labor. After ninety (90) days, and for the remainder of the one year warranty period, your warranty covers parts alone. Certain limitations and exclusions apply.

### DEALERS & CONSUMERS:

Dealers and consumers can return any In-Warranty Channel Master product to the Warranty department for repair or replacement. For In-Warranty service the consumer or dealer must call Technical Service and request an RMA number in order to return the product. The returned product must have the RMA number visible on the box and must include the bill of sale showing the unit is within the warranty period. If the unit is found to be defective under our Warranty Policy Channel Master will repair or replace the item at no charge. Products outside of the warranty period should not be returned to Channel Master with the exception of any product requested by Technical Support to be accessed for quality assurance purposes. Technical Service Phone: +1.877.746.7261 \* Some products have extended term warranty periods.

### WARRANTY: EFFECTIVE IMMEDIATELY

### GENERAL TERMS:

**1.1** Subject to the provisions of this Warranty, CHANNEL MASTER warrants that the equipment and software described in Paragraph **1.2** will conform to our specifications in all material respect and that the equipment will be free from material defects in materials and workmanship during the Limited Warranty period. **1.2** This Warranty applies to all original purchases by Customers of CHANNEL MASTER ("Equipment"). The warranties set forth herein are not transferable. **1.3** The Effective period of this Warranty will start on the date of purchase of the Equipment or the date of installation by a CHANNEL MASTER approved technician and will end, for the Equipment, ninety (90) day later (for all component parts and system upgrades), unless otherwise expressed or provided herein (in each case the "Warranty Period").

### RETURN OF EQUIPMENT UNDER WARRANTY:

**2.1** If an item of Equipment malfunctions or fails in normal use within the applicable Warranty Period: **(a)** The Customer shall notify CHANNEL MASTER within thirty (30) days of the problem. **(b)** CHANNEL MASTER will, at its option, either resolve the problem over the telephone or provide the customer with a Return Authorization ("RMA") Number and the address to which the customer may ship the defective item; **(c)** If the problem can not be resolved over the telephone, the Customer shall attach a label showing the RMA number to each returned item, and include a description of the problem. The Customer shall, at his or her own cost, properly pack the item to be returned, mark the RMA# on the outside of the box, prepay the insurance and shipping charges, and ship the item to the specified CHANNEL MASTER location. **(d)** Unauthorized return of any equipment, whether in or out of warranty, will be subject to a handling charge, in addition to all repair and all transportation charges. **(e)** CHANNEL MASTER will, at its sole option, repair or replace the returned item. If replaced, the replacement item may be new or refurbished; if refurbished it will be equivalent in operation to new Equipment. If a returned item is replaced by CHANNEL MASTER, the Customer agrees that the returned item will become the property of CHANNEL MASTER. **(f)** CHANNEL MASTER will complete the exchange of CHANNEL MASTER manufactured equipment returned under this Warranty within a reasonable time, subject to lead-times from factory, and will make a good faith effort to minimize any and all delays where possible; and **(g)** CHANNEL MASTER will, at its cost, ship the repaired item or replacement to the Customer. If the Customer requests express shipping, the Customer will pay CHANNEL MASTER an expediting fee.

**2.2** Equipment which is repaired or replaced by CHANNEL MASTER under this Warranty will be covered under all of the provisions of this Warranty for the remainder of the applicable Warranty period (for that particular equipment) from the date of repair or replacement, whichever is longer. **2.3** If equipment is repaired beyond effective warranty dates or if abnormal usage had occurred, Customer shall be charged applicable rates and the Customer will be advised of the estimated charges prior to repair by CHANNEL MASTER's authorized service center. **2.4** The price of out-



of-warranty repairs payable by the Customer will be based on standard labor and parts prices in effect at the time of the repair. CHANNEL MASTER will use its best efforts to ensure that the cost of such repair, exchange, refurbishing, or substitution will not exceed the original price of Product. **2.5** If the problem reoccurs within the warranty period, CHANNEL MASTER will, at its option: **(1)** re-perform the service; **(2)** replace the product pursuant to the terms of this warranty, **(3)** permit Customer to return the product and issue a refund pursuant to this warrant, or **(4)** refund the amount the Customer paid for the services.

### PRODUCT MODIFICATION:

**4.1** CHANNEL MASTER reserves the right to make changes or improvements to its products, during subsequent production, without incurring the obligation to install such changes or improvements on previously manufactured or sold products. **FORCE MAJEURE: 5.1** CHANNEL MASTER will not be liable if its performance under this warranty becomes commercially impracticable due to any contingency beyond CHANNEL MASTER's reasonable control, including acts of God, fires, flood, wars, sabotage, civil unrest, accidents, labor disputes or shortages, government laws, rules and regulations, whether valid or invalid, inability to obtain material, equipment or transportation, incorrect, delayed or incomplete specifications, drawings or data supplied by Customer (collectively "Force Majeure").

### LIMITATIONS AND QUALIFICATIONS OF WARRANTY:

**6.1** This Limited Warranty extends only to the original purchaser of the Equipment and is in lieu of all other express or implied warranties, including those of merchantability and fitness for a particular purpose. **This Warranty does not apply to any damage, defect of failure caused by:** **(a)** any part of the equipment having been modified, adapted, repaired, maintained, transported or relocated by any person; **(b)** Storage or environmental characteristics which do not conform to the applicable sections of the appropriate Equipment Manual or Instruction Sheet; **(c)** Failure to conform with the Equipment Operating Instructions in the applicable Equipment Manual or Instruction Sheet; **(d)** External causes, including external electrical stress or lightning, or use in conjunction with incompatible equipment, unless such use was with CHANNEL MASTER's prior written request; **(e)** Cosmetic damage; **(f)** Accidental damage, negligence, modification, mishandling, abuse or misuse; or **(g)** Force Majeure. **Warranty does not cover:** **(a)** Labor charges for installation or setup of the product. **(b)** Any taxes imposed on CHANNEL MASTER for units replaced or repaired under this warranty. **(c)** Installation, performance of, or repair of: audio/video cabling, telephone line, or accessory attachments used with the product. **(d)** Product replacement because of misuse, accident, lightning damage, unauthorized repair, or other cause not within the control of CHANNEL MASTER. Please note that removing the cover of the Unit for any reason voids the warranty. **(e)** Reception transmission problems caused by signal conditions, telephone line, or cable or antenna systems outside the unit. **(f)** Damages to, or viruses that may infect your Unit or other devices arising from the use of unauthorized third party devices in connection with your Unit. **(g)** Incidental or consequential damages resulting from the product. (Some states (or jurisdictions) do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.) **(h)** A product that has been modified or adapted to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications. **(i)** A product used for commercial or institutional purposes. **(j)** Access connections (telephone or broadband), including charges from your communications provider.

### LIMITATION ON DAMAGES:

**7.1** THIS WARRANTY IS THE CUSTOMER'S EXCLUSIVE WARRANTY FOR THE EQUIPMENT, CHANNEL MASTER SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, EXPRESSED OR IMPLIED, INCLUDING ANY WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND OF MERCHANTABILITY. **7.2** CHANNEL MASTER WILL NOT BE LIABLE IN TORT, INCLUDING LIABILITY IN NEGLIGENCE OR STRICT LIABILITY, AND WILL HAVE NO LIABILITY AT ALL FOR INJURY TO PERSONS OR PROPERTY. CHANNEL MASTER'S LIABILITY FOR FAILURE TO FULFILL ITS OBLIGATIONS UNDER THIS WARRANTY OR ANY OTHER LIABILITY UNDER OR IN CONNECTION WITH THE EQUIPMENT WILL BE LIMITED TO THE AMOUNT OF THE PURCHASE PRICE OF THE EQUIPMENT AT THE TIME OF ORIGINAL PURCHASE. THE REMEDIES STATED IN THIS WARRANTY ARE THE CUSTOMER'S EXCLUSIVE REMEDIES AGAINST CHANNEL MASTER REGARDING THE EQUIPMENT. **7.3** EVEN IF CHANNEL MASTER HAS BEEN NOTIFIED OF THE POSSIBILITY OF THEM, CHANNEL MASTER WILL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, INCLUDING LOST PROFITS AND REVENUES, FAILURE TO REALIZE EXPECTED SAVINGS, ANY CLAIM AGAINST A CUSTOMER BY A THIRD PARTY, OR ANY OTHER COMMERCIAL OR ECONOMIC LOSSES OF ANY KIND. **7.4** THESE LIMITATIONS AND DISCLAIMERS ARE NOT MADE BY CHANNEL MASTER WHERE PROHIBITED BY LAW.

# *Channel Master*<sup>®</sup>

[ChannelMaster.com](http://ChannelMaster.com)



© 2011 Channel Master. Channel Master and Channel Master TV are trademarks of Channel Master. Other company, product, and service names may be trademarks or service marks of others. All information contained in this document is subject to change without notice. Information contained in this document is provided on an as is basis. In no event will Channel Master be liable for damages arising directly or indirectly from any use of the information contained in this document. Contents subject to change without notice. 99-708004-09CM